

Quadriceps tendon tensile test

1. 10g find contact load
2. 6% maximum strain
3. Protocol: find contact->preconditioning->find contact->stress relaxation.
4. 1000 preconditioning cycles, max strain

oks00TR2-QAT-CXXX-01-01 lengths: 10.557 (for preconditioning),10.8950mm (for stress relaxation)
oks00TR2-QAT-CXXX-01-02 lengths: 11.0210 (for preconditioning), 11.180mm (for stress relaxation)
oks00TR2-QAT-CXXX-01-03 lengths: 11.1865 (for preconditioning), 11.2845mm (for stress relaxation)

