

Quadriceps tendon failure test:

1. Protocol: find contact->preconditioning 1000 cycles, 6% strain ->find contact->20%/s strain rate load to failure.

2. Specimen starts to fail around 7.5% strain. 6% therefore is picked as a safe limit

oks00TR2-QAT-CXXX-02-01 : lengths: 10.8095 (for preconditioning), 11.199 mm(for stress relaxation)

